



1. Detach speakers.




2. Remove Cables.




3. Connect speakers and power.



4. Connect mics and instruments.



5. Reduce levels then power on!



6. Adjust master and channel levels.